
Determination of Total Dissolved Gas Levels below Dams on the Columbia River


Region 10 Informational Workshop


Portland, OR

July 24, 2001

Basic Process







Henry's Law

"the weight of any gas that dissolves in a given volume of a liquid, at a constant temperature, is directly proportional to the pressure that the gas exerts on the liquid"

$$p = H_e C_s$$

Mass Transfer Rates


dC


Basic Assumptions for TDG Production

- TDG exchange is an equilibrium process
- ☐ Flow through the powerhouse is not exposed to entrained air bubbles (all through spillway)
- Powerhouse waters can mix with spillway waters and get exposed to entrained bubbles below dam

Dissolved Gas Saturation Levels


$$S_{tdg} = \underbrace{(P_{atm +} \Delta P)}_{P_{atm}} \times 100$$






Determination of Average TDG Pressures

$$\begin{aligned} P_{avg} &= (Q_{sp} + Q_e)P_{sp} + (Q_{ph} - Q_e)P_{ph} \\ &\qquad \qquad Q_{sp} + Q_{ph} \end{aligned}$$






Calculating TDG

High TDG levels in waters below dams are a function of these key factors:

- ☐ Flow over spillway
- Depth of water in tailrace
- Amount of powerhouse flow entrained with spillway flow



Final Formulations

$$\Delta P = C_1 D_{tw} (1 - e^{-C_2 q_s}) + C_3$$

$$\Delta P = C_1 D_{tw}^{C_2} q_s^{C_3} + C_4$$

$$\Delta P = C_1 D_{tw}^{C_2} q_s^{C_3} + C_4$$

Use for TMDL Development

- Empirical coefficients for each dam project determine flow/depth relationship to TDG production
- Determination of gas production under various discharge scenrios
- Determine allowable flow rate discharge to meet defined TMDL targets

